

Q. How do you set up the Parking Lot Feature in your PBX?

1. In your PBX admin portal select “Parking Lot” from your options on the left hand side.

Parking Lot Options


Enable Parking Lot Feature 2

Parking Lot Extension: 70 3

Number of Slots: 8 4

Parking Timeout: 1 minute, 30 seconds 5

Parking Lot Context: ~~parkedcalls~~



2. Click the check box to “Enable Parking Lot Feature”.
3. Choose the extension where you will transfer a call to park it. Default is set to 70.
4. Choose the number of parking lot spaces to configure. E.g. if 70 is the extension and 8 slots are configured, the parking slots will be 71-78.
5. Choose the timeout period that a parked call will attempt to ring back the original parker if not answered.

6. Choose the destination of the parked call if the call is not picked up from the parking stall.
7. Click Submit
8. Click “Apply Configuration Changes”
9. Click “Continue with Reload”



Apply Configuration Changes

Reloading will apply all configuration changes made in FreePBX to your PBX engine and make them active.

Continue with reload **9**

Cancel reload and go back to editing

Actions for Timed-Out Orphans

~~Parking Alert-Info:~~
~~CallerID Prepend:~~
~~Announcement: None ▾~~

Destination for Orphaned Parked Calls:

Terminate Call: ▾

Extensions: ▾

Voicemail: ▾

IVR: ▾ **6**

Misc Destinations: ▾

Ring Groups: ▾

Time Conditions: ▾

7